



Install Driver on ChromeBook(ChromeOS) via USB cable

It takes a few minutes to show how to install FlashLabel Printer driver on ChromeBook(ChromeOS):


1. Search and add "Flashlabel" extension in the Chrome Web Store.



2. Click the extension icon -> Choose "FlashLabel" -> Click "Add" -> Choose "Y810" -> Click "Connect".



Tips: You can change Speed, Density, Resolution in "Setting Printer" menu.



Add FlashLabel Printer

Setting Printer


1. Insert printer and click Add button to enter the device list, then Select the printer

2. Open the file to print

3. Please do not close this web page. After closing, you will not be able to select flashprinter.

4. After the printer is added successfully, if you close this web page accidentally, you can reopen this web page without adding a printer again

Add



3. Open a PDF file with Chrome Browser -> Choose "FlashLabel" and your paper size -> Click "Print".

P

SAMPLE LABEL 062S0009993642
6 LB PRIORITY MAIL RATE 7689597
ZONE 4 NO SURCHARGE FROM 98610
COMMERCIAL PLUS PRICING

PRIORITY MAIL 2-DAY™

John Smith **99**
1234 BARNES RD
CARSON NV 30000

SHIP TO: DO NOT SHIP
11 CAMPBELL AVE
CAMPBELL CA 95009

USPS TRACKING #



888888888888888888888888888888

DO NOT SHIP

Print 1 sheet of paper

Destination **FlashLabel**

Pages All

Copies 1

Paper size ISO_4.00x6.00 inch

Pages per sheet 1

Scale Default

Print using system dialog... (⌘%P)

Open PDF in Preview

Cancel **Print**